



1369 N. Killian Drive, Lake Park, FL 33403

tel 561-845-7888 · fax 561-845-6777 · www.renntechmercedes.com

©Copyright 2003 Renntech, Inc. All rights reserved. Distribution of this document, including but not limited to distribution on the Internet is expressly prohibited unless approved in writing by Renntech, Inc.

Instructions for removing the TCU on S-Class W220/CL-Class W215

1. Open the hood of the vehicle. On each side of the hood hinges, depress the tab first on the driver's side and then on the passenger side. This will allow you to open the hood even further and will come to rest in a vertical position.
2. Remove the fuse box cover on the passenger side of the engine bay to gain access to the transmission computer.



3. The transmission computer is tucked away on the outer most side of the fuse box.



4. With a small screwdriver or punch, depress the tab on the connector while pulling up gently. **Note:** Do not pull on the wires. The length of the wires will only allow you to move the computer up only about an inch, but you must remove the connectors first before you can remove the computer.



5. Now you can remove the computer.



6. Re-install the transmission computer in reverse order.