



1369 N. Killian Drive, Lake Park, FL 33403

tel 561-845-7888 · fax 561-845-6777 · www.renntechmercedes.com

©Copyright 2003 Renntech, Inc. All rights reserved. Distribution of this document, including but not limited to distribution on the Internet is expressly prohibited unless approved in writing by Renntech, Inc.

Instructions for removing the TCU R230 SL Class

1. Lift up the carpet on the passenger side floorboard.



2. Remove the plastic screw cap that hides the screw that holds the kick panel. Remove the screw and then the kick panel.



3. With the kick panel removed, you gained access to the transmission computer. Depress the tabs on the connectors and remove the wires carefully. With the wires disconnected, you can then remove the computer. The computer just slides out and is held in with clips on the chassis.



4. Re-install the transmission computer in reverse order.